



**Klipsch® DETROIT**




# 同梱品

スピーカー本体・USB Type-Cケーブル




# 着脱可能なストラップ

---



# ボタンの説明

---



**ON / OFF**

電源オン/オフ

**Bluetooth®**

Bluetooth®

**Volume Down**


音量ダウン

**Volume Up**

音量アップ


# 充電方法

---




# USBを使用したリバース充電

---



# BLUETOOTH® ワイヤレス接続

---




BLUETOOTH®ボタンを  
1秒間長押しします



接続中は点滅しています


\* 画像は一例です。お使いのデバイスにより異なります。




接続が完了すると点灯します

# ステレオモード

---



BLUETOOTH®ボタンとマイナスボタンを  
1秒間同時に押します






連携させたい2台目のBLUETOOTH®ボタンと  
マイナスボタンを1秒間同時に押します

3~5秒程すると、両方のスピーカーから  
同時に連携完了の通知音が鳴ります



連携完了後、1台はBLUETOOTH®ボタンが点灯、もう1台は点滅します  
点灯している本体を向かって左側に置くと音源本来のL（左）R（右）と一致します




L




R

# ブロードキャストモード

---



BLUETOOTH®ボタンとプラスボタンを  
1秒間同時に押します




連携させたい2台目以降のBLUETOOTH®  
ボタンとプラスボタンを  
1秒間同時に押します

3~5秒程すると、両方のスピーカーから  
同時に連携完了の通知音が鳴ります


---

ブロードキャストモードでのペアリング中はボタンが白く点滅しています



# お手入れについて

乾いた布で優しく拭いてください




## 工場出荷時の状態へ戻す

充電ケーブルは刺さず、BLUETOOTH®ボタンとプラスボタンを5秒間同時に押します  
「FACTORY RESET」の音声が流れれば完了です



5秒間長押し

“FACTORY RESET”



# アプリのインストール


---




## Klipsch Connect Plus

- App Store
- Google Play


製品登録、イコライザー調整など  
無料でご使用頂けます



VIRTUAL REMOTE



EQUALIZER



CHANNEL CONTROL



SUPPORT



©2024, Klipsch Group, Inc. Klipsch Group, Inc. is a wholly-owned subsidiary of Vox International Corporation. Klipsch and Keepers of the Sound are trademarks of Klipsch Group, Inc., registered in the United States and other countries. The *Bluetooth*® word mark is a registered trademark owned by Bluetooth SIG, Inc. and any use of such mark by Klipsch Group, Inc. is under license.

V02 - 240710